

Dear Officer,

Congratulations on obtaining the cutting-edge Portable Safe, a state-ofthe-art device designed to secure critical assets in the field. In your hands, you now hold a marvel of Raccoon City Police Department engineering. To ensure optimal usage, please adhere to the following instructions:

I. Activation and Operation:

A. Power On:

- Introduce the right combination by pressing the buttons in the correct order.

B. Opening Sequence:

- Upon successful entry of the correct combination, the opening sequence will commence, marked by a unique light pattern and sound.
- To close the safe and initiate the process again, close the lid and, while applying slight pressure, press and hold **button 1 for 2** seconds. The lock will securely close.

II. Configuration Mode:

A. Access:

- When turning on the device, press and hold button 8 for 3 seconds to enter configuration mode.
- The device will emit a distinct sound signaling "Config mode activated" accompanied by a rapid blinking of all green LEDs.

B. Options in Config Mode:

1. Set Static Sequence (Button 1):

- Pressing button 1 allows you to establish a static sequence.
- The device will announce "Enter custom sequence" enabling you to press the buttons in your desired order.
- The sequence will be saved upon pressing the last of the 8 buttons, accompanied by a confirmation sound: "Custom sequence saved"
- Please note that, when solving the sequence, there is more than one correct combination for entering the right sequence. For instance, if you input the button combination 1, 2, 3, 4, 5, 6, 7, 8, another valid combination could be 5, 6, 7, 8, 1, 2, 3, 4.



- 2. Enable Random Sequence Mode (Button 2):
 - Pressing button 2 activates random sequence mode, confirmed by the device with the announcement "Random sequence mode enabled".
- 3. Control Locker Motor Opening Direction (Button 3):
 - Pressing button 3 grants control over the locker motor, moving it in the "opening" direction.
 - The motor will continue moving as long as the button is pressed, useful in troubleshooting situations.
- 4. Control Locker Motor Closing Direction (Button 4):
 - Pressing button 4 provides control over the locker motor, moving it in the "closing" direction.
 - The motor will operate as long as the button is held down, aiding in resolving any issues with safe functionality.

C. Exit:

- To exit config mode, press and hold button 8 for 3 seconds.
- The device will emit a sound indicating "Config mode deactivated" and all green LEDs will blink rapidly three times.

III. Easter Egg Discovery:

- Within the Portable Safe lies the potential for a hidden surprise waiting to be unearthed. Keen users may find an undisclosed feature that adds an element of mystery and delight to their experience.

Annex: Device Schema and Additional Information

- Refer to the attached schema for button-number correlation. Scan the QR code or visit the link for extra details, including a copy of this letter and other insights.

We trust that these instructions will enhance your experience with the Portable Safe. Remember, security is paramount in our line of duty, and this device stands as a testament to our commitment to excellence.

Stay vigilant.

Sincerely,

Jill Valentine Special Tactics and Rescue Service (S.T.A.R.S.) Raccoon City Police Department



ANNEX:



Device Layout and Button Correspondence



https://jvlobo.com/portable-safe/